

TABLE 4. PERIODIC MAINTENANCE SCHEDULE

MAINTENANCE PROCEDURE	MAINTENANCE FREQUENCY							Page
	Every Day or Every 8 Hours	After First 20 Hours	Every Month	Every 50 Hours	Every 150 Hours		Every 450 Hours	
General Inspections	X							
Check Engine Oil Level	X							
Clean and Check Battery			X ³					
Clean Spark Arrestor				X				
Change Engine Oil		X ¹			X ^{2,3,4}			
Replace Air Filter Element					X ²			
Clean Engine Cooling Fins						X ²		
Replace Spark Plug							X ⁵	-
Replace Fuel Filter							X ⁵	-
Adjust Valve Lash							X ⁶	-
<p>1 - As a part of engine break-in, change the engine oil after the first 20 hours of operation. 2 - Perform more often when operating in dusty environments. 3 - Perform more often when operating in hot weather. 4 - Perform at least once a year. 5 - Perform sooner if engine performance deteriorates. 6 - Must be performed by a qualified mechanic (authorized Onan dealer).</p>								